

Contents lists available at ScienceDirect

Data in Brief

journal homepage: www.elsevier.com/locate/dib

Data Article

Experimental data of the aqueous  $NH_3$  and  $CO_2$ absorption at temperatures from 15 °C to 35 °C,  $NH_3$  concentrations from 5% to 15% and  $CO_2$ loadings from 0.2 to 0.6 measured with the Wetted Wall Column

Stefano Lillia <sup>a,\*</sup>, Davide Bonalumi <sup>a</sup>, Philip L. Fosbøl <sup>b</sup>, Kaj Thomsen <sup>b</sup>, Gianluca Valenti <sup>a</sup>

 <sup>a</sup> Politecnico di Milano, Dipartimento di Energia, Via R. Lambruschini 4, 20156 Milano, Italy
 <sup>b</sup> Technical University of Danemark, Department of Chemical Engineering, Center for Energy Resource Engineering, Søltofs Plads, 2800 Kgs. Lyngby, Denmark

# ARTICLE INFO

Article history: Received 23 January 2018 Received in revised form 30 January 2018 Accepted 15 February 2018 Available online 2 March 2018

# ABSTRACT

The absorption between aqueous  $NH_3$  and  $CO_2$  is studied using the Wetted Wall Column in order to show the effect of the solvent condition on the rate of reaction. A total of 27 different cases are investigated in the region defined by temperatures from  $15 \,^{\circ}C$  to  $35 \,^{\circ}C$ ,  $NH_3$  concentrations from 5% to 15% and  $CO_2$  loadings from 0.2 to 0.6. The paper reports the data measured during the experiments, the experimental apparatus description and the experimental procedure. The data here presented are both the raw data measured with their uncertainty and the final value of the overall mass transfer coefficient. The overall mass transfer coefficient is the result of the raw data treatment explained in the research paper related to this data. The data here reported are analyzed in the paper by Lillia et al. (2018) [1].

© 2018 The Authors. Published by Elsevier Inc. This is an open access article under the CC BY license (http://creativecommons.org/licenses/by/4.0/).

DOI of original article: https://doi.org/10.1016/j.ijggc.2018.01.009

https://doi.org/10.1016/j.dib.2018.02.047

2352-3409/© 2018 The Authors. Published by Elsevier Inc. This is an open access article under the CC BY license (http://creativecommons.org/licenses/by/4.0/).

<sup>\*</sup> Corresponding author.

E-mail address: stefano.lillia@polimi.it (S. Lillia).

<b>Nomenclature</b> Acronyms		$P_i^j$	partial pressure of component <i>i</i> at position j [mol/s]	
VR	Value Read Full-Scale Wetted Wall Column Liquid phase Gas phase	Greek symbols		
FS WWC Liq. Gas		$arphi_{{ m CO}_2}$	$CO_2$ flux absorbed by the solvent [mol/(m <sup>2</sup> s)]	
Symbols				
K <sub>ov</sub>	overall mass transfer coefficient for the $CO_2$ transport [mol/(Pa m <sup>2</sup> s)]			

# **Specifications Table**

Subject area More specific sub- ject area	Environmental chemical engineering Absorption solvent characterization and rate of the absorption measurements
Type of data	Table of data and text
How data was acquired	The data are acquired by the Wetted Wall Column apparatus. The partial pressure of the $CO_2$ inside the reactor is measured considering the total pressure in the reactor with a pressure transducer (Rosmount 2088) and the $CO_2$ concentration with the $CO_2$ probe (VAISALA GMT 220). The $CO_2$ flow absorbed by the solvent in the reactor is measured considering the difference of the $CO_2$ concentration with the $CO_2$ probe (VAISALA GMT 220) before and after the reactor and the gas mole flow blown to the reactor.
Data format	Raw measurements with uncertainties and their analysis (the overall mass transfer coefficient).
Experimental factors	The solvent is prepared gravimetrically in terms of ammonia composition and $CO_2$ loading (defined as the rapport of $CO_2$ and $NH_3$ in the solvent).
Experimental features	A gas mixture of $N_2$ and $CO_2$ with a known composition flows in the Wetted Wall Column in contact with solvent with a known composition. The partial pressure of the $CO_2$ inside the reaction chamber and the $CO_2$ flux absorbed by the solvent are measured during the experiment for different compositions of gas and sol- vent. The result is the overall mass transfer coefficient which describes the dependence of the rate of absorption and the partial pressure of the $CO_2$ .
Data source location	Department of Energy of Politecnico di Milano, Milan (Italy)
Data accessibility	Data are provided within the attached excel file and within the article
Related research article	Experimental study of the aqueous $CO_2$ -NH <sub>3</sub> rate of reaction for temperatures from 15 °C to 35 °C, NH <sub>3</sub> concentrations from 5% to 15% and $CO_2$ loadings from 0.2 to 0.6 [1]

# Value of the data

- Enhance the number of analyzed cases for the CO<sub>2</sub> capture with ammonia solvents
- Raw data with their uncertainties provide information about the accuracy of the measures and the
  procedure used.
- Raw data are treated to compute the overall mass transfer coefficient under the hypothesis explained by Lillia et al. [1]. Other researcher can model the phenomenon under other hypothesis and treat the raw data with different procedures and compare the *K*<sub>ov</sub> results found.
- *K*<sub>ov</sub> value can be compared with other data in literature and new data measured in future works with the same method.

#### 1. Data

The data provided by the paper are the Wetted Wall Column measurements for every case analyzed with the absolute uncertainty. The aim of the measurements is the calculation of the CO<sub>2</sub> flux absorbed by the solvent and the partial pressure of the CO<sub>2</sub> inside the Wetted Wall Column reactor. The data presented are the raw data measured by the Wetted Wall Column apparatus and their analysis following the procedure explained in the relative research article by [1]. The raw data treatment returns the overall mass transfer coefficient  $K_{ov}$  [mol/(m<sup>2</sup> s Pa)] that correlates the difference of CO<sub>2</sub> partial pressure in the reaction chamber and the CO<sub>2</sub> flux absorbed by the solvent as defined in Eq. (1)

$$\varphi_{CO_2} = K_{ov} \left( P_{CO_2}^{gas} - P_{CO_2}^{liq} \right) \tag{1}$$

where  $\varphi_{CO_2}$  [mol/(s m<sup>2</sup>)] is the total CO<sub>2</sub> molar flux absorbed,  $P_{CO_2}^{gas}$  [Pa] is the partial pressure of carbon dioxide in the bulk gas and  $P_{CO_2}^{liq}$  [Pa] the partial pressure of carbon dioxide in the bulk liquid. This constant identifies both the effect of the rate of reaction and the mass transfer of the CO<sub>2</sub> and it is usually reported in this kind of experimental work. Hence, also the value of the  $K_{ov}$  is reported with its uncertainty.



**Fig. 1.** Wetted Wall Column set up pictures: (i) on the left the picture depicts the overall Wetted wall Column set up, (ii) on the right the picture shows a focus on the reaction chamber where the absorption reaction takes place.

Quantity measured	Manufacturer	Model	Range	Uncertainty
N <sub>2</sub> Flow [Ndm <sup>3</sup> /min] CO <sub>2</sub> Flow [Ndm <sup>3</sup> /min] Pressure [mbar] CO <sub>2</sub> concentration [dimensionless] Temperature [°C] Density [g/cm <sup>3</sup> ] Viscosity [mPa s]	Bronkhorst Bronkhorst Rosmount VAISALA TC Direct Anton-Paar Anton-Paar	F-201 CV F-201 CV 2088 GMT 220 Pt 100 1/3 DIN DMA 4100 AMV 200	0–20 [Ndm <sup>3</sup> /min] 0–2 [Ndm <sup>3</sup> /min] 0–9900 [mbar] 0–0.1 [dimensionless] – 50 °C to 200 °C 0–3 [g/cm <sup>3</sup> ]	$\begin{array}{c} 0.005VR + 0.001FS\\ 0.005VR + 0.001FS\\ 0.001FS\\ 0.02VR + 0.002\\ 0.03VR + 0.0005FS\\ 5 * 10^{-5}[g/cm^3]\\ 0.001[mPas] \end{array}$

Table 1 Instrumentation list.

# 2. Experimental design, materials, and methods

#### 2.1. Wetted Wall Column (WWC) experimental apparatus

Fig. 1 shows the experimental apparatus used in this work and Table 1 presents the instrument list. The Wetted Wall Column allows for counter-current contact between the liquid solvent and a defined gas mixture.  $CO_2$  and  $N_2$  are supplied by gas bottles with a molar purity of 99.995% and 99.996% respectively. The streams from the bottles are controlled by two Bronkhorst mass flow controllers which determine the composition of the inlet mixture in the chamber. The gas mixture passes through a pre-saturator at ambient temperature and a saturator immersed in a thermostatic bath at the temperature of the experiment. After the saturators, the gas mixture is saturated with water at the same temperature of the thermostatic bath. Between the reaction chamber and the  $CO_2$  concentration probe (VAISALA CARBOCAP GMT 221) is positioned a condenser. The saturators and the condenser are necessary in order to have a known amount of water in the gas and consequently determine accurately the amount of  $CO_2$  in the gas flow. Before the reaction chamber, in the gas line, there is a bypass valve. The valve allows to measure the carbon dioxide concentration before and after the absorption reactions switching the flow straight to the  $CO_2$  probe or to the reaction chamber.

The thermostatic bath controls the temperature of the reaction chamber and the temperature of the inlet solvent in the reaction chamber. The solvent, prepared with a known NH<sub>3</sub> concentration and  $CO_2$  loading is charged in a liquid reservoir of 0.7 dm<sup>3</sup>. A micro pump pushes the liquid with a controlled mass flow into the thermostatic bath and then into the reaction chamber. The reaction chamber consists of a glass tube in which a stainless steel tube is located (dimensions are reported in Fig. 1). The liquid, pushed inside the stainless steel tube, falls down in a thin film around the stainless steel tube. In this way the contact area between the liquid and the gas phase is well defined.

Based on the known contact area between the gas and the liquid, and the amount of CO<sub>2</sub> absorbed in the chamber, it is possible to determine the dependence between the CO<sub>2</sub> surface flux absorbed by the liquid and the CO<sub>2</sub> partial pressure in the gas mixture at a fixed temperature. A clear scheme of the plant layout is available in the Fig. 1 in the second paragraph of the article which describes the experimental data analysis [1].

# 2.2. Solvent preparation procedure

The solvent is identified by two numbers: (i) the ammonia concentration, defined as the initial weight of ammonia on the weight of water (wt. NH<sub>3</sub>/wt. H<sub>2</sub>O) and (ii) the CO<sub>2</sub> loading defined as the ratio between the CO<sub>2</sub> and the ammonia in the solution. The chemicals used to prepare the solutions are: deionized water, ammonia solution 28 wt% and ammonium bicarbonate NH<sub>4</sub>HCO<sub>3</sub>. The solvent is prepared gravimetrically with a balance with an accuracy of 0.01 g and a full scale of 1000 g. The ammonia concentration and the CO<sub>2</sub> loading is calculated considering the apparent concentration of H<sub>2</sub>O, NH<sub>3</sub> and CO<sub>2</sub>. Deionized water is considered pure H<sub>2</sub>O, ammonia solution is 28 wt% NH<sub>3</sub> and 72 wt% H<sub>2</sub>O, and one molecule of NH<sub>4</sub>HCO<sub>3</sub> is one molecule NH<sub>3</sub> plus one molecule H<sub>2</sub>O plus one molecule CO<sub>2</sub>.

# 2.3. Experimental procedure

The experimental procedure for measuring the overall mass transfer coefficient is described by the following points:

- 1. prepare the solvent with the desired ammonia concentration and loading;
- 2. measure the density and the viscosity of the solvent;
- 3. flush the system with nitrogen for at least 15 min, corresponding to more than 300 reaction chamber volumes;
- 4. introduce the solvent in the experimental setup and pump the solvent in the liquid circuit until it forms a stable and uniform liquid film on the cylinder in the reaction chamber;
- 5. set the temperature of the thermostatic bath and wait that the temperature of the reaction chamber is stable at the desired value;
- 6. when the  $CO_2$  probe reports a null concentration of  $CO_2$  the set-up is ready for the experiment;
- 7. send a flow of N<sub>2</sub> and CO<sub>2</sub> with the desired concentration into the bypass gas line and measure the CO<sub>2</sub> concentration at steady state condition;
- 8. direct the gas to the reaction chamber and measure the CO<sub>2</sub> concentration at steady state condition;
- 9. repeat the last two points for four other different gas mixtures;
- 10. measure five points at different concentration of  $CO_2$  following the procedure here described in the points 7–9;
- 11. flow nitrogen in the set-up for 20–30 min and at least 10 l of water in order to clean up the set-up;

This procedure has been repeated at temperatures of 15 °C, 25 °C and 35 °C, ammonia concentrations of 5%, 10% and 15% and CO<sub>2</sub> loadings of 0.2, 0.4 and 0.6 (0.5 for 15% of ammonia to avoid salt precipitations) for a total of 27 cases ( $3 \times 3 \times 3$ ).

# Transparency document. Supplementary material

Transparency document associated with this article can be found in the online version at doi:10. 1016/j.dib.2018.02.047.

# Appendix A. Supplementary material

Supplementary data associated with this article can be found in the online version at doi:10.1016/j. dib.2018.02.047.

# Reference

[1] S. Lillia, D. Bonalumi, P.L. Fosbøl, K. Thomsen, G. Valenti, Experimental study of the aqueous CO<sub>2</sub>-NH<sub>3</sub> rate of reaction for temperatures from 15 °C to 35 °C, NH<sub>3</sub> concentrations from 5% to 15% and CO<sub>2</sub> loadings from 0.2 to 0.6, Int. J. Greenh. Gas. Control (2018), http://dx.doi.org/10.1016/j.ijggc.2018.01.009.

1244